



8.4 TOL Tolerance and warning limits display. This function allows for quick recognition of good parts and tolerance deviations. Includes diagrams for tolerance limits and warning limits.

Digitale Bügel-Messschraube Digital Micrometer Micrometre digital Micrometro digital 数字千尺. Includes a diagram of the micrometer and technical specifications.

8.5 MENÜ 8.5 MENU. Navigation in the menu, setting parameters. Includes diagrams for menu navigation and parameter adjustment.

8.5 菜单键包含的功能 8.5.1 直观的菜单操作, 设置参数. Includes diagrams for menu navigation and parameter adjustment.

8.5.2 Menüfunktionen 8.5.2 Menu functions. Includes diagrams for menu functions and parameter settings.

8.5.2 菜单键包含的功能 8.5.2 直观的菜单操作, 设置参数. Includes diagrams for menu functions and parameter settings.

8.5.3 Strukturdiagramm der Menüfunktionen 8.5.3 Structure diagram of menu functions. Includes a flowchart showing the menu structure.

8.5.3 菜单功能结构图. Includes a flowchart showing the menu structure.

8.5.4 ORIGIN-Wert eingeben 8.5.4 Enter ORIGIN value. Includes diagrams for entering the origin value.

8.5.4 设置预置值. Includes diagrams for setting the origin value.

8.5.5 Datenkommunikation 8.5.5 Data communication. Includes diagrams for data communication and USB connections.

8.5.5 数据通信. Includes diagrams for data communication and USB connections.

9. Displaymeldungen 9. Display Messages. Includes diagrams for error messages and display settings.

9. 提示信息. Includes diagrams for error messages and display settings.

9.1 "Error"-Fehlermeldung 9.1 "Error" message. Includes diagrams for error messages and display settings.

9.1 "错误"消息. Includes diagrams for error messages and display settings.

9.2 /Bedientasten gesperrt 9.2 / Operating keys locked. Includes diagrams for locked keys and display settings.

9.2 / 此按键锁功能开启被. Includes diagrams for locked keys and display settings.

9.3 d Loc / einzelne Funktionen gesperrt 9.3 d Loc / Individual functions locked. Includes diagrams for individual function locks and display settings.

9.3 d Loc / 个体功能已锁定. Includes diagrams for individual function locks and display settings.

9.4 Battery-Symbol / Lo Bat-Meldung 9.4 Battery symbol / Lo Bat message. Includes diagrams for battery status and display settings.

9.4 电池符号 / Low Bat 消息. Includes diagrams for battery status and display settings.

9.5 „no Fct“-Fehlermeldung 9.5 "no Fct" error message. Includes diagrams for no Fct error and display settings.

9.5 "no Fct" 错误消息. Includes diagrams for no Fct error and display settings.

Bestätigung der Rückführbarkeit 9. Confirmation of traceability. Includes diagrams for traceability confirmation.

可追溯性声明. Includes diagrams for traceability confirmation.

Eisorgungsinweise 9. Notes for disposal. Includes diagrams for disposal instructions.

回收处理. Includes diagrams for disposal instructions.

9.1 "Error"-Fehlermeldung 9.1 "Error" message. Includes diagrams for error messages and display settings.

9.1 "错误"消息. Includes diagrams for error messages and display settings.

9.2 /Bedientasten gesperrt 9.2 / Operating keys locked. Includes diagrams for locked keys and display settings.

9.2 / 此按键锁功能开启被. Includes diagrams for locked keys and display settings.

9.3 d Loc / einzelne Funktionen gesperrt 9.3 d Loc / Individual functions locked. Includes diagrams for individual function locks and display settings.

9.3 d Loc / 个体功能已锁定. Includes diagrams for individual function locks and display settings.

9.4 Battery-Symbol / Lo Bat-Meldung 9.4 Battery symbol / Lo Bat message. Includes diagrams for battery status and display settings.

9.4 电池符号 / Low Bat 消息. Includes diagrams for battery status and display settings.

9.5 „no Fct“-Fehlermeldung 9.5 "no Fct" error message. Includes diagrams for no Fct error and display settings.

9.5 "no Fct" 错误消息. Includes diagrams for no Fct error and display settings.

Bestätigung der Rückführbarkeit 9. Confirmation of traceability. Includes diagrams for traceability confirmation.

可追溯性声明. Includes diagrams for traceability confirmation.

Eisorgungsinweise 9. Notes for disposal. Includes diagrams for disposal instructions.

回收处理. Includes diagrams for disposal instructions.

9.1 "Error"-Fehlermeldung 9.1 "Error" message. Includes diagrams for error messages and display settings.

9.1 "错误"消息. Includes diagrams for error messages and display settings.

9.2 /Bedientasten gesperrt 9.2 / Operating keys locked. Includes diagrams for locked keys and display settings.

9.2 / 此按键锁功能开启被. Includes diagrams for locked keys and display settings.

9.3 d Loc / einzelne Funktionen gesperrt 9.3 d Loc / Individual functions locked. Includes diagrams for individual function locks and display settings.

9.3 d Loc / 个体功能已锁定. Includes diagrams for individual function locks and display settings.

9.4 Battery-Symbol / Lo Bat-Meldung 9.4 Battery symbol / Lo Bat message. Includes diagrams for battery status and display settings.

9.4 电池符号 / Low Bat 消息. Includes diagrams for battery status and display settings.

9.5 „no Fct“-Fehlermeldung 9.5 "no Fct" error message. Includes diagrams for no Fct error and display settings.

9.5 "no Fct" 错误消息. Includes diagrams for no Fct error and display settings.

Bestätigung der Rückführbarkeit 9. Confirmation of traceability. Includes diagrams for traceability confirmation.

可追溯性声明. Includes diagrams for traceability confirmation.

Eisorgungsinweise 9. Notes for disposal. Includes diagrams for disposal instructions.

回收处理. Includes diagrams for disposal instructions.

9.1 "Error"-Fehlermeldung 9.1 "Error" message. Includes diagrams for error messages and display settings.

9.1 "错误"消息. Includes diagrams for error messages and display settings.

9.2 /Bedientasten gesperrt 9.2 / Operating keys locked. Includes diagrams for locked keys and display settings.

9.2 / 此按键锁功能开启被. Includes diagrams for locked keys and display settings.

9.3 d Loc / einzelne Funktionen gesperrt 9.3 d Loc / Individual functions locked. Includes diagrams for individual function locks and display settings.

9.3 d Loc / 个体功能已锁定. Includes diagrams for individual function locks and display settings.

9.4 Battery-Symbol / Lo Bat-Meldung 9.4 Battery symbol / Lo Bat message. Includes diagrams for battery status and display settings.

9.4 电池符号 / Low Bat 消息. Includes diagrams for battery status and display settings.

9.5 „no Fct“-Fehlermeldung 9.5 "no Fct" error message. Includes diagrams for no Fct error and display settings.

9.5 "no Fct" 错误消息. Includes diagrams for no Fct error and display settings.

Bestätigung der Rückführbarkeit 9. Confirmation of traceability. Includes diagrams for traceability confirmation.

可追溯性声明. Includes diagrams for traceability confirmation.

Eisorgungsinweise 9. Notes for disposal. Includes diagrams for disposal instructions.

回收处理. Includes diagrams for disposal instructions.

9.1 "Error"-Fehlermeldung 9.1 "Error" message. Includes diagrams for error messages and display settings.

9.1 "错误"消息. Includes diagrams for error messages and display settings.

9.2 /Bedientasten gesperrt 9.2 / Operating keys locked. Includes diagrams for locked keys and display settings.

9.2 / 此按键锁功能开启被. Includes diagrams for locked keys and display settings.

9.3 d Loc / einzelne Funktionen gesperrt 9.3 d Loc / Individual functions locked. Includes diagrams for individual function locks and display settings.

9.3 d Loc / 个体功能已锁定. Includes diagrams for individual function locks and display settings.

9.4 Battery-Symbol / Lo Bat-Meldung 9.4 Battery symbol / Lo Bat message. Includes diagrams for battery status and display settings.

9.4 电池符号 / Low Bat 消息. Includes diagrams for battery status and display settings.

9.5 „no Fct“-Fehlermeldung 9.5 "no Fct" error message. Includes diagrams for no Fct error and display settings.

9.5 "no Fct" 错误消息. Includes diagrams for no Fct error and display settings.

Bestätigung der Rückführbarkeit 9. Confirmation of traceability. Includes diagrams for traceability confirmation.

可追溯性声明. Includes diagrams for traceability confirmation.

Eisorgungsinweise 9. Notes for disposal. Includes diagrams for disposal instructions.

回收处理. Includes diagrams for disposal instructions.

9.1 "Error"-Fehlermeldung 9.1 "Error" message. Includes diagrams for error messages and display settings.

9.1 "错误"消息. Includes diagrams for error messages and display settings.

9.2 /Bedientasten gesperrt 9.2 / Operating keys locked. Includes diagrams for locked keys and display settings.

9.2 / 此按键锁功能开启被. Includes diagrams for locked keys and display settings.

9.3 d Loc / einzelne Funktionen gesperrt 9.3 d Loc / Individual functions locked. Includes diagrams for individual function locks and display settings.

9.3 d Loc / 个体功能已锁定. Includes diagrams for individual function locks and display settings.

9.4 Battery-Symbol / Lo Bat-Meldung 9.4 Battery symbol / Lo Bat message. Includes diagrams for battery status and display settings.

9.4 电池符号 / Low Bat 消息. Includes diagrams for battery status and display settings.

9.5 „no Fct“-Fehlermeldung 9.5 "no Fct" error message. Includes diagrams for no Fct error and display settings.

9.5 "no Fct" 错误消息. Includes diagrams for no Fct error and display settings.